


2 - ASSEMBLY MAIN BEARING HOUSING - MODEL - 4 x 5 ESV NL



2 - ASSEMBLY MAIN BEARING HOUSING - MODEL - 4 x 5 ESV NL

Sr.No	Description	Ref Part Nos	Qty
-	-- ASSEMBLY MB HOUSING 5STK ESV	42316141	-
2-1	---- HOUSING MB WITH BUSH 5INCH ESV	37073624	1
2-4	---- SCREW CAP HEX HEAD 5/8 X 3-1/4	95104477	2
2-5	---- O-RING 10-1/2 X 11 X 1/4	95098067	1
2-6	---- ELBOW MAIN BEARING HOUSING-0.50 NPT	94425162	1
-	---- BREATHER OIL FILL ASSY	39677737	1
2-7	----- BREATHER ELBOW CAST AL.	39314323	1
2-10	----- CAP BREATHER	30557888	1
2-9	---- ADAPTER OIL FILTER	30179220	1
2-11	---- BUSH MBH 5ESV	30557557	1
2-12	---- PLUG COUNTER SHUNK 3/8IN NPT	95101705	2