


## 2. BARE COMPRESSOR - MODEL 5T2NL



## 2. BARE COMPRESSOR - MODEL 5T2NL

No.	Description	Ref Part No.	QTY
2-1	Assembly, Tube - Pilot Valve/Breather - Complete1.	32241523	1
2-2	Bottle, Breather Trap	32225534	1
2-3	Plug, Breather Element	32225526	1
2-4	Nipple, Hex - 3/8"	32230864	1
2-5	Nipple, Close - 3/8 X 1'	95691077	1
2-6	Elbow, Pipe - 3/8' - 45°	95030672	1
2-7	Assembly, Tube - Breather Trap - Completet	32241549	1
2-8	Gasket, Airhead - High Pressure	30294508	1
2-9	Assembly, Airhead/Valve - High Pressure	32226318	1
2-10	- Valve, 35 - Complete (See Figure 3, Page 8)	37004827	1
2-11	- Airhead, Bottom	32222705	1
2-12	- Dowel	37114030	1
2-13	- Gasket, Airhead - Top/Bottom	37007754	1
2-14	- Airhead, Top	32226177	1
2-15	- Spring, Unloader Pin	32012395	2
2-16	- Plate, Unloader - Complete	32016578	1
2-17	- Body, Unloader	37129889	1
2-18	- Gasket, Unloader Body	30294680	1
2-19	- Piston, Unloader	32222507	1
2-20	- O-Ring, Unloader Piston	32225468	1
2-21	- Spring, Unloader Piston	30416853	1
2-22	- Cover, Unloader	37129905	1
2-23	- Gasket, Unloader Cover	30294656	1
2-24	- Washer - M10	32225286	4
2-25	- Capscrew - M10 X 85	32225138	4
2-26	Capscrew - M12 X 75	32225146	6
2-27	Gasket, Airhead - Low Pressure	30294193	1
2-28	Assembly, Airhead/Valve - Low Pressure	32226300	1
2-29	- Valve, 50 - Complete (See Figure 4, Page 9)	37004843	1
2-30	- Airhead, Bottom	32222739	1
2-31	- Dowel	37114030	1
2-32	- Gasket, Airhead - Top/Bottom	37007747	1
2-33	- Airhead, Top	32226185	1
2-34	- Spring, Unloader Pin	32012395	3
2-35	- Plate, Unloader - Complete	32222788	1
2-36	- Body, Unloader	37129947	1
2-37	- Gasket, Unloader Body	30294698	1
2-38	- Piston, Unloader	32222507	1

## 2. BARE COMPRESSOR - MODEL 5T2NL

No.	Description	Ref Part No.	QTY
2-39	– O-Ring, Unloader Piston	32225468	1
2-40	– Spring, Unloader Piston	30416853	1
2-41	– Cover, Unloader	37129905	1
2-42	– Gasket, Unloader Cover	30294656	1
2-43	– Washer - M10	32225286	4
2-44	– Capscrew - M10 X 90	32225138	4
2-45	Capscrew - M12 X 75	32225146	6